



KEY	PART #	DESCRIPTION	KEY	PART #	DESCRIPTION
1	H40061	Cutlery Bin, 4-Compartment, Gray	11	H10048	Tong, 9", Yellow, S/S
2	H80019	French Fry Scale	12	H10114	Salt Shaker Dredge w/Handle, S/S
3	H10079	Order Holder, 30"	13	H10191	Fry Scoop, Right Handle
4	QTDIVSBS	Half Moon Divider, 3-Tab	14	H70085	French Fry Channel, 38"
5	H70060	Coin Changer, Standard	n/s	H70074	French Fry Channel, 17"
6	H80015	Timer, Digital, 24-hr, AC/DC	15	H70061	Coin Changer w/Bumper
7	H50119	Timer, 24-hr w/Memory	16	WV217735-98	Divider Weldment
8	H10127	Fry Scoop, Nylon, RH	17	H40116	Carhop Tray, Red
9	H70062	Fry Carton Dispenser, Regular			
10	H10047	Tong, 9", Red, S/S			